

# WASTE STATION AUTOFEED

Improve health & hygiene · Reduce your environmental impact · Maximise cost efficiencies



The B&M Waste Station Autofeed builds on the compact waste station and allows more than the single bucket feed of the Waste Station and Waste Station CR. Food waste is emptied into the collection chamber and auger fed into the maceration chamber before being pumped to the remote drying unit, which can be up to 55m away. This ensures maximum efficiency in busy kitchens / prep areas.

## Key Benefits:

- Through the remote de-watering system, waste volume is reduced by up to 80% and mass by up to 60%
- Greater utilisation of staff as many buckets can be discharged in a short time (200kg)
- Cleaner and more hygienic kitchen area as waste is transported directly away into a dedicated waste collection area

## Key Components:

- Food waste from the hopper is automatically auger-fed directly into the built-in macerating chamber
- Macerated waste is then automatically pumped into the remote de-watering system up to 55m away
- Capacity of 200 litres
- Optional tipper

**Contact us today for  
your free quote  
0330 1234 100  
equipment@bandmwaste.com**